

# TEMPLATE FOR 32F SERIES MAGNALOCK (FACE MOUNT)

!!! WARNING: DO NOT DRILL INTO MAGNET OR STRIKE FOR ANY REASON !!!

1. See installation instructions and Z-Bracket instructions for full information and troubleshooting.
2. The relationship between the two magnet mounting holes is critical. Do not let your marking or drilling wander.
3. Do not overdrill the diameter of the 3/8" [9.5mm] magnet mounting holes or the blind nuts will not seat. It is best to use a center punch to create the indentations for all drill locations.
4. Do not over tighten the magnet mounting screws. Use threadlocker provided when mounting screws.
5. The two rubber washers stack one on top of the other and mount in between the strike and the Z-Bracket around the center strike mounting screw. Don't place the washers on the roll pins.
6. Make sure the strike plate floats and pivots around the center mounting screw. This compensates for door misalignment. If the strike is mounted rigidly, the Magnalock will not hold.
7. Use of roll pin plastic bushings is recommended for metal doors. If the plastic bushings are not used, drill 3/8" [9.5mm] diameter holes for the strike roll pins.
8. DO NOT PHOTOCOPY TEMPLATE (dimensions will change).

